


Fleet Camera Installer App Quick Guide







Dimension Settings a. Install Position Riaht 🗸 b. Bonnet length (Oinch - 120inch) c. Vehicle Width (40inch - 120inch) d. Camera Height (40inch - 120inch)




Select camera setup


Select units desired Select vehicle type

Enter camera position and measurements taken during installation

Select Installed if driver facing camera was installed



Select camera WiFi network (camera serial number) & Enter password (located on camera)



Select OK to continue



Set vehicle angle as per instruction here




Fleet Camera Installer App Quick Guide





Camera angle is good when level indicators are green Select **OK** once complete







Select *Camera View* to adjust driver facing camera angle There is no qualification for this camera, close when satisfied Select Next to proceed



Select *Check device* if you would like to view camera angles again Select OK to continue Select **Next** to continue



When complete you should receive the message above Select OK to continue



Once you have reached this screen your QA & configuration is complete